



RC-51 UNDERTAIL

RU25263

We at Rumble concept encourage all installations to be performed by a professional. If you choose to install this product, please read all instructions and take all appropriate safety measures to ensure the proper and safe installation of your new undertail.

Before installation:

our undertails have been designed for modification purposes, we are not responsible for the use or misuse of any products, or verification of the local department of motor vehicles.

1. Remove both seat

2. Remove complete tail section

3. Remove the reflectors on each side by drilling the rivets.(see picture)

4. Flip the CDI box under the transversal bar of the sub frame while installation.(see picture)

5. Cut the mudguard (Stock undertail) following the green line (See 3 pictures)



6. Mount the lock on your new undertail using your original honda clipping

7. Re-install the stock tail section along without fixing it and then gently slide the undertail (Tail light, turn signal, lock already nstall on it) in is position.

8. Do all your connections, test evrything and finally fix the tail section...

9. HAVE A GOOD RIDE...!

